

THERMOSTAT SCHEDULE:

T-STAT #	Bus/Address #	ZONE	MODEL	WIRE	1ST STAGE	2ND STAGE	COOLING	AUX SENSORS	NOTES
TO BE FILLED IN LATER									
<p>THE TEKMAR THERMOSTATS WILL ESTABLISH A COMMUNICATION NETWORK WHEN THE TNS TERMINALS ARE CONNECTED TO A TNS BUS. ALL THERMOSTATS ARE ASSIGNED AN ADDRESS NUMBER ON THE NETWORK. THE ADDRESS INCLUDES THE BUS WATER TEMPERATURE DESIGNATION AND DEVICE NUMBER. BUS WATER TEMPERATURE DESIGNATIONS ARE AVAILABLE AS BOILER (B), MIX1 (1), MIX2 (2), ETC. THE DEVICE NUMBER CAN RANGE FROM 1 TO 24. TO CHECK THE ADDRESS NUMBER FOR A THERMOSTAT GO TO THE MISCELLANEOUS MENU AND THE NUMBER IS DISPLAYED IN THE TREN FIELD. WRITE THE ADDRESS NUMBER IN THE BUS/ADDRESS # FIELD FOR FUTURE REFERENCE.</p>									
1	B01	1-NEW ZONE	TE541	18-4	X			X	ROOM SENSOR

KEY TO COMMON SYMBOLS

PRESTIGE PARAMETER 4, THE MAXIMUM BOILER OPERATING TEMPERATURE, IS PRESET TO 186°F. THIS SETTING IS REQUIRED FOR THE BOILER TO OPERATE UP TO HIGHER TEMPERATURES TO RECOVER THE INDIRECT WATER HEATER. THIS SETTING SHOULD BE CONFIRMED AND ACTS AS A HIGH LIMIT CUT OUT FOR THE BOILER AS THE TEKMAR 420 CONTROL IS NOT DESIGNED TO PERFORM THE FUNCTION AS A SAFETY HIGH LIMIT DEVICE.

AND

PARAMETER 45 (CH OPERATING SIGNAL SELECTION) NEEDS TO BE CHANGED FROM 00 TO 02. THIS WILL ALLOW THE PRESTIGE TO MODULATE WITH A 1.8 TO 10VDC INPUT SIGNAL FROM THE TEKMAR 420 CONTROL


CONDENSATE FROM THE PRESTIGE WILL BE SLIGHTLY ACIDIC - TYPICALLY WITH A PH FROM 3.2 TO 4.5. INSTALL A NEUTRALIZER IF REQUIRED BY CODE.

BOILER OPERATION NOTE:

THE TEKMAR 420 CONTROL IS SENDING A 1.8 TO 10 VDC MODULATED HEAT DEMAND TO THE PRESTIGE BOILER TO DETERMINE THE OPERATING TEMPERATURE OF THE BOILER. THIS WILL ALLOW FOR THE RADIANT FLOOR HEATING SYSTEM TO OPERATE WITH ALL THE FEATURES AVAILABLE THROUGH THE TEKMAR CONTROLS INCLUDING INDOOR AND OUTDOOR FEEDBACK, ZONE SYNCHRONIZATION, AND DOMESTIC HOT WATER PRIORITY.

TEKMAR OPERATIONAL NOTE:

THE TEKMAR 420 CONTROL IS OPERATING IN A TWO WATER TEMPERATURE MODE. THE RADIANT HEATING MODE WILL PROVIDE SUPPLY RADIANT WATER TEMPERATURES UP TO 105°F UNDER DESIGN CONDITIONS. THE DOMESTIC HOT WATER MODE WILL PROVIDE HOT WATER FROM THE BOILER TO THE INDIRECT STORAGE TANK UP TO 180°F WITH PRIORITY OVER SPACE HEATING. 180°F SUPPLY WATER TEMPERATURE IS TOO HOT FOR SPACE HEATING AND COULD RESULT IN DAMAGE TO THE FLOOR COVERINGS AND CREATE EXPANSION NOISE IN THE SYSTEM. CONFIRM **DHW MODE 2** IS SET ON THE TEKMAR 420 CONTROLLER (ADJUST MENU PARAMETER) AND OPERATE THE SYSTEM TO VERIFY THE HEATING SYSTEM ZONES WILL SHUT DOWN DURING A CALL FOR DOMESTIC HOT WATER HEATING.






PUMP SCHEDULE

PS - GRUNDFOS ALPHA 15-55 F
SET TO THE **CONSTANT PRESSURE** MODE.

PD - GRUNDFOS UPS 15-58F
SET TO SPEED HI

Grundfos Alpha Circulators Require Integral Check in the Discharge Volute.

**** DISCLAIMER ****
BOILER EQUIPMENT AND INSTALLATION MUST MEET ALL MANUFACTURER INSTRUCTION AND LOCAL CODES AND SUPERSEDES THE INFORMATION DETAILED ON THIS DIAGRAM



541 ESSENTIAL SETTINGS (WITH FLOOR SENSOR)

ITEM FIELD	SETTING	ITEM FIELD	SETTING
Mode	Heat	Scene	On
Set Occ	Per User	Select	Perm 1
Set Unocc	Per User	Set Perm 1	Schedule
Set Away	Per User		
Floor Min Occ*	Per User		
Floor Min UnOcc	Off		
Floor Max	Off		
Sensor 1	Floor		
Room Sensor	On		
H1 Terminal	Control		
H1 Pump	On		
H1 Delay	Off		
Cool Member	None		
(Opt Start/Stop)	On		

The initial thermostat set up can be quite complicated with the Scene the Scheduling options that are available. Initial setup of the thermostat can be greatly simplified by setting the 'Heat Set' to 'None', and the 'Scene' feature to 'Off'.

* Set slab minimum to the same as room heat. If the room is to warm for comfort decrease slab minimum temperature. If the floor is cool for comfort increase slab minimum temperature.


542 ESSENTIAL SETTINGS (WITH FLOOR SENSOR)

ITEM FIELD	SETTING	ITEM FIELD	SETTING
Mode	Heat	Scene	On
Set Occ	Per User	Select	Perm 1
Set Unocc	Per User	Set Perm 1	Schedule
Set Away	Per User		
Floor Min Occ*	Per User		
Floor Min UnOcc	Off		
Floor Max	Off		
Sensor 1	Floor		
Room Sensor	On		
H1 Terminal	Control		
H1 Pump	On		
H1 Delay	Off		
Cool Member	None		
WWSD Control	Control		
(Opt Start/Stop)	On		

The schedule menu settings are shown configured for the simplest setback schedule including the same schedule for each day of the week and two events per day. More scheduling options are possible, please refer to the data brochures for additional information.

The initial thermostat set up can be quite complicated with the Scene the Scheduling options that are available. Initial setup of the thermostat can be greatly simplified by setting the 'Heat Set' to 'None', and the 'Scene' feature to 'Off'.


* Set slab minimum to the same as room heat. If the room is to warm for comfort decrease slab minimum temperature. If the floor is cool for comfort increase slab minimum temperature.




THERMOSTAT DISPLAY SYMBOLS

Display	Meaning
Off	Thermostat is off
Heat	Thermostat in Heating Mode
H1	Thermostat is calling for heat
Away	Thermostat is in away mode
(Symbol)	Thermostat is on the Network


Tekmar thermostats include four different access levels. The Access level restricts the number of menus, items and adjustments that can be accessed by the user. To Access these features, it is required that the Access Level located in the Miscellaneous menu be set to 'Advanced' instead of 'User' (Default). After programming, the Access level can be set to the level most appropriate for the user.




MSTR BED (PROGRAMMABLE)




LOFT




GUEST BED




BED 1 / BED 2



BASMENT



MAIN




BONUS



STUDY / LAUNDRY



1ST FL MAIN



JUMPER REQUIRED

EXTERNAL HEAT DEMAND TO PRESTIGE BOILERS NOT REQUIRED

MUST BE SET TO MODULATING BOILER

TEST

DO NOT APPLY POWER

TEKMAR ZONE MANAGER 335

TEKMAR MIXING RESET MODULE 420

88°F

POWER: ZONE A1, ZONE A2, ZONE A3, ZONE A4, ZONE A5, ZONE A6

ESSENTIAL DIP SWITCH SETTINGS

120 VAC L N

NOT USED

TEKMAR ZONE MANAGER 335

POWER: ZONE A1, ZONE A2, ZONE A3, ZONE A4, ZONE A5, ZONE A6

ESSENTIAL DIP SWITCH SETTINGS

120 VAC L N

NOT USED

TEKMAR ZONE MANAGER 335

POWER: ZONE A1, ZONE A2, ZONE A3, ZONE A4, ZONE A5, ZONE A6

ESSENTIAL DIP SWITCH SETTINGS

120 VAC L N

NOT USED

TEKMAR ZONE MANAGER 335

POWER: ZONE A1, ZONE A2, ZONE A3, ZONE A4, ZONE A5, ZONE A6

ESSENTIAL DIP SWITCH SETTINGS

120 VAC L N

NOT USED

TEKMAR ZONE MANAGER 335

POWER: ZONE A1, ZONE A2, ZONE A3, ZONE A4, ZONE A5, ZONE A6

ESSENTIAL DIP SWITCH SETTINGS

120 VAC L N

NOT USED

TEKMAR ZONE MANAGER 335

POWER: ZONE A1, ZONE A2, ZONE A3, ZONE A4, ZONE A5, ZONE A6

ESSENTIAL DIP SWITCH SETTINGS

120 VAC L N

NOT USED

TEKMAR ZONE MANAGER 335

POWER: ZONE A1, ZONE A2, ZONE A3, ZONE A4, ZONE A5, ZONE A6

ESSENTIAL DIP SWITCH SETTINGS

120 VAC L N

NOT USED

TEKMAR ZONE MANAGER 335

POWER: ZONE A1, ZONE A2, ZONE A3, ZONE A4, ZONE A5, ZONE A6

ESSENTIAL DIP SWITCH SETTINGS

120 VAC L N

NOT USED

TEKMAR ZONE MANAGER 335

POWER: ZONE A1, ZONE A2, ZONE A3, ZONE A4, ZONE A5, ZONE A6

ESSENTIAL DIP SWITCH SETTINGS

120 VAC L N

NOT USED

TEKMAR ZONE MANAGER 335

POWER: ZONE A1, ZONE A2, ZONE A3, ZONE A4, ZONE A5, ZONE A6

ESSENTIAL DIP SWITCH SETTINGS

120 VAC L N

NOT USED

420 ESSENTIAL SETTINGS ADJUST MENU

ITEM FIELD	SETTING
Outdoor Design	-5°F
Boiler Term	HRF2
Boiler Indoor	70°F
Boiler Design**	105°F
Boiler Min*	OFF
Boiler Max	190°F
Fire Delay*	0:35 Min
Boiler Diff*	Au (Auto)
Boiler Motor*	90 Seconds
Min. Modulation*	18%
Max. Modulation*	100%
Cyc (Cycles/hr)*	Au (Auto)
Schedule	OFF
DHW Mode	2
DHW Exch Occ	180°F
Setpoint Mode	Off
WWSD Occ	65°F

* Item Settings Per Tekmar Specifications


** The Maximum Radiant Floor Heating Supply Water Temperature Setting Could be 10°F Higher Than Boiler Design

TESTING THE CONTROL

PRESS AND HOLD THE TEST BUTTON FOR ONE SECOND TO TEST THE ITEMS CONNECTED TO THE 420 CONTROL. THE CONTROL WILL RUN THROUGH A SEQUENCE. TO ADVANCE TO A PARTICULAR STEP, REPEATEDLY PRESS AND RELEASE THE TEST BUTTON.

PRESS AND HOLD THE TEST BUTTON FOR SIX SECONDS TO TEST THE ITEMS CONNECTED TO THE ZONE CONTROLLERS. PRESS THE UP BUTTON TO CHANGE THE DISPLAY TO 'ZN TEST'. THE CONTROL OPERATES ONE ZONE AT A TIME AND ALL OTHER DEVICES ARE SHUT OFF. USE THE ARROW BUTTONS TO CHANGE THE DEVICE NUMBER TO BE TESTED.

THE TEKMAR 420 HAS TWO DIFFERENT ACCESS LEVELS. THESE ACCESS LEVELS RESTRICTS THE NUMBER OF MENUS, ITEMS AND ADJUSTMENTS THAT CAN BE ACCESSED BY THE USER. THE ACCESS LEVEL SETTING IS FOUND IN THE MISCELLANEOUS (MISC) MENU. THE FACTORY DEFAULT SETTING IS INSTALLER (INS). TO HAVE ACCESS TO ALL THE SETTINGS REQUIRED, CHANGE THE SETTING TO ADVANCED (AD).



THERMOSTAT OPERATIONAL NOTES

Tekmar IN4 thermostats include a number of advanced features to increase both the comfort and energy efficiency for your radiant heating system. One of these features is the ability to form a communications network. The purpose of this document is to highlight some of the network features to allow the user to utilize the network to identify thermostats and assist in locating and correcting network errors.

Tekmar thermostats include five different access levels. The Access level restricts the number of menus, items and adjustments that can be accessed by the user. The Access Level is located in the Miscellaneous menu and is usually set to Advanced instead of User (Default) for initial set up. This will allow the user access to all the settings available to the thermostat. After the settings are determined and set, the thermostat access level can be set for the people who use the thermostat on a regular basis.

The Tekmar thermostat will establish a communication network when the IN4 terminals are connected to a IN4 bus. All Thermostats are assigned an address number on the network. The address includes the bus water temperature designation and device number. Bus water temperature designations are available as Boiler (b), Mix1 (1), Mix2 (2), Etc. The device number can range from 1 to 24. To check the address number for a thermostat go to the miscellaneous menu and the number is displayed in the Item field. The LCD will flash "Auto" then "B.A.A" where B is the bus number and AA is the address number. The "Auto" means the address number has been automatically assigned. It is important to keep track of the address numbers to be able to troubleshoot when the thermostat encounters an error. The literature for each thermostat includes a Job Record Sheet which is a good place to record the data.

When the thermostat encounters an error, a Warning Symbol appears in the upper right corner of all thermostat displays and the tekmar boiler control. The thermostat will display the error in the view menu (as long as the thermostat is in the 'Installer' or 'Advanced' access modes. Refer to the thermostat data brochure for resolution of the error. Note if the thermostat is in the 'View' menu, the 'Item' button must be pressed until the error is displayed. If the thermostat is in another menu, then press the 'Menu' button and the 'View' menu will display the error without the need to scroll with the 'Item' button.

When the thermostat encounters an error, a Warning Symbol appears in the upper right corner of all thermostat displays and the tekmar boiler control. The thermostat will display the error in the view menu (as long as the thermostat is in the 'Installer' or 'Advanced' access modes. Refer to the thermostat data brochure for resolution of the error. Note if the thermostat is in the 'View' menu, the 'Item' button must be pressed until the error is displayed. If the thermostat is in another menu, then press the 'Menu' button and the 'View' menu will display the error without the need to scroll with the 'Item' button.

Finally, the tekmar boiler controls will keep track of the number of devices (thermostats) on the network. If the device count changes (a thermostat is removed from the network, for example), the tekmar boiler control might display the 'Warning Symbol'. Sometimes the error message will clear automatically and other times the error message will remain. To clear the error message in the 'View' menu, scroll with the 'Item' button until the error is displayed. Then press and hold 'Up' and 'Down' arrow buttons until the error is removed.

Power Down The Controllers When Making Thermostat Connections Or Risk Blowing Low Voltage Fuse. Blown fuses is indicated by the power LED displayed in the color AMBER.

TERMINAL STRIP OPTIONAL FOR EASE OF INSTALLATION AND TESTING AT THE MANIFOLD

YELLOW WIRES NO POLARITY

WIRING NOTES:

- IT IS IMPORTANT TO PREVENT INDUCED ELECTRICAL INTERFERENCE IN SENSOR WIRING. DO NOT RUN RTU OR OTHER SENSOR WIRES ALONGSIDE LINE VOLTAGE WIRING OF NEAR MOTOR CONTACTORS. IF NECESSARY, CROSS THE LINE VOLTAGE AND SENSOR WIRES PERPENDICULAR TO EACH OTHER. IF LARGE MOTORS, HEAT PUMPS OR OTHER SOURCES OF ELECTRICAL NOISE SUCH AS ELECTRONIC BOILER IGNITION SYSTEMS ARE LOCATED NEAR THE SENSORS, THEN SHIELDED CABLE OF METAL CONDUIT IS REQUIRED FOR RTU OR SENSOR WIRING.
- REFER TO EQUIPMENT DATA SHEETS FOR ADDITIONAL WIRING AND OPERATIONAL DETAILS AND SAFETY INFORMATION NOT DESCRIBED IN THIS WIRING DIAGRAM.
- FOR CLARITY, GROUNDING OF EQUIPMENT IS OMITTED ON THIS WIRING DIAGRAM. ALL EQUIPMENT SHOULD BE GROUNDED IN ACCORDANCE WITH NEC AND LOCAL CODES.

